

Active 2D® lightning conductor

Excitation with Time control by impulse and sustained propagation


Active 2D® AFV0101TT remote tester

Active 2D® can be tested on site, with his remote tester (initial checking, periodic checking,...)

Active 2D® remote testers use the communication by Radio waves, and create any electromagnetic perturbation.

A battery provides this tester with power supply (battery provided).

The LCD display indicates the (positive or negative) result straightaway.




Effective working until 100 m of distance in free field.

The test guarantees that the lightning conductor is ready to work.



Use of AFV0101TT remote control tester

1. Press  during 2 seconds
2. The LCD display switch on indicating the autotest positive result: the tester is now working.
3. Function 1 blinks during testing and communicating with the lightning rod
4. The four LCD display switch on to indicate that the lightning conductor is working.

Other situations :

- Any LCD display switch on : 9V battery of the tester should be replaced
- Only function 1 switch on : the communication with the lightning rod did not work
- Only function 2 switch on : the identification of the lightning rod did not work.
- Only function 3 switch on : the lightning rod is not working

- Contact <http://www.franklin-france.com>

Franklin France
e-mail : franklin@franklin-france.com